

HILTI

CS-FT EPDM E

Instructions for use

Surfaces to which the foil tape is to be applied must be dry and free from oil, grease or dust. Unroll the CS-ADH EPDM E foil tape and cut it to size, allowing approx. 5 cm extra length. Pull off the paper cover strip and press the self-adhesive tape against the surface of the window frame, pressing it down firmly. Repeat this procedure on all edges of the window frame where a seal is to be formed. Bring the window frame into position, align it correctly and fasten securely in place. Any gaps remaining between the window frame and the wall must be filled completely with insulating material, e.g. using Joint Sealing Foam CS-F JS. For bonding to masonry surfaces we recommend use of Foil Adhesive CS-ADH MS 600. For an airtight seal on the interior side of the frame we recommend use of Active Membrane CS-FT AM or Internal Membrane CS-FT IM FX.

Disposal

Scraps of tape may be disposed of together with household waste. Locally applicable regulations must be observed.

Special instructions

Observe the instructions for use! Useful information can also be found in the brochure "Plastering over window frame joint sealing tapes", published by the Bundesverband der Gipsindustrie e.V. – Industriegruppe (German trade association for plasterers).

Safety instructions

On the basis of the currently available data and experience already gained, the product does not require to be classed as a dangerous material in accordance with the dangerous materials regulations. Nevertheless, we recommend that the usual measures regarding care and hygiene when handling chemical substances are observed.

Cleaning

The skin should be cleaned with soap and water. Adhesive remains can be removed with the aid of a benzene-based cleaning agent. Please observe all applicable safety precautions.

HILTI

CS-FT EPDM E

Verarbeitung

Die Haftflächen müssen trocken, öl-, fett- und staubfrei sein. Folienband CS-ADH EPDM E abrollen und mit ca. 5 cm Überlänge zuschneiden. Das Abdeckpapier abziehen und den Befestigungsstreifen sorgfältig an den Fensterrücken andrücken. Vorgang an allen abzudichtenden Seiten des Fensters wiederholen. Das Fensterelement ausrichten und befestigen und den Hohlraum zwischen Fenster und Wand vollständig mit Dämmmaterial, z.B. Fugendichtschaum CS-F JS, dosiert verfüllen. Für Verklebungen auf dem Mauerwerksuntergrund empfehlen wir Folienkleber CS-ADH MS 600. Für die luftdichte Innenabdichtung empfehlen wir Wechselklimamembran CS-FT AM oder Innenmembran CS-FT IM FX.

Entsorgung

Bandreste können mit dem Hausmüll entsorgt werden. Örtliche Vorschriften sind zu beachten.

Besondere Hinweise

Beachten Sie die Verarbeitungshinweise! Nützliche Informationen erhalten Sie auch in der Broschüre „Verputzen von Fensteranschlussfolien“, Bundesverband der Gipsindustrie e.V. – Industriegruppe

Sicherheitshinweise

Das Produkt ist auf Grund vorliegender Daten und Erfahrungen kein Gefahrstoff im Sinne der Gefahrstoffverordnung und der entsprechenden EG-Richtlinien. Wir empfehlen aber, die für den Umgang mit chemischen Stoffen übliche Sorgfalt und Hygiene zu beachten.

Reinigung

Hautreinigungen mit Wasser und Seife. Entfernung von Kleberresten ist mit einem Reinigungsmittel auf Benzinbasis möglich. Bitte Sicherheitsvorschriften beachten.